



CARB#D-489-2

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part #'s Dragon intake : 804-115

Application : 1991-1994 240SX 16V

Parts List : 1 x Intake pipe. / 1 x Air Filter / 2 x 2.75"x 2.75" coupler / 1 X 3"- 3" coupler/ 2 x 15mm x 12" hose

2 x 10mm x 12" hose/1 x Intake Bracket kit / 6 x 3" Clamp / 1 x AFM-NS Adapter plate

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the 15mm PCV and 1x 10mm 1 x 15mm Air recirculator hoses from OEM intake.
- 3 Remove the 10mm hose form the top of OEM airbox and from AIV induction box.
- 4 Loosen the clamp on the 1.5" hose on the Air Resonator box connected to OEM intake.
- 5 Leave the 1.5" hose in original location.
- 6 Unplug and remove the MAF sensor from the air intake system.
- 7 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 8 Install the 2.75-2.75" coupler onto throttlebody, secure with OEM clamp.
- 9 Insert Weapon*R intake pipe into the coupler, secure with clamp.
- 10 Install the supplied 15mm hose onto the intake pipe and to the PCV valve on valvecover.
- 11 Install the supplied 1 x 10mm/1x 15mm hose onto the intake pipe and to the air recirculator valves.
- 12 Install the 2.75"-2.75" coupler onto end of intake pipe, secure with clamp.
- 13 Insert MAF into the 2.75-2.75" coupler, secure with clamp
- 14 Line up the holes on MAF to the AFM-NS adapter plate, secure with nuts and bolts in kit.
- 15 Install 3"-3" coupler onto MAF plate and clamp down.
- 16 Install WR filter onto 3"-3" coupler and clamp down
- 17 Install 10mm hose to WR pipe then to AIV induction box.

Note: Dragon Filter Option :

- 18 Install U-shaped part of intake system bracket under the clamp on air filter.
- 19 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 20 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 21 Secure with washer and nut included in bracket kit.
- 22 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 23 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 24 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.



8HP & 5FT TORQUE GAIN !

The Accord test car recently went through a Power Page session in the shop, which yielded a max of 152.2 horsepower. After adding the Weapon R regulator and doing a hot an over 145 psi, max horsepower almost paralleled the baseline. One of the major changes between the two graphs is that horsepower gain in the low and mid-range rpm areas. Right from the graph baseline, there's a noticeable increase in torque that is four more hp-hr over the stock baseline run. Horsepower also benefited in the same region, showing a gradual gain of one to four horsepower before leveling off at the top.

Fuel Pressure regulator kit also available for this vehicle , for more info check our website.

If you have any Question about this Product, Please refer to our website @ WWW.WEAPON-R.COM