



## ZSpeed CMAK V2 with Stock Style OEM Clutch Pressure Plate

To use the stock pressure plate with the ZSPEED CMAK it is recommended to remove the “over center bracket” This is done simply by cutting the bracket in the 6 locations marked in red.

This is not needed when not using the stock style clutch concentric clutch slave.

Make the cuts as even as possible so you do not upset the balance of the pressure plate.

Cut at red lines.

Cut here

After Cutting

