

PLATINUM SERIES

Haltech I/O Expander 12 HT059900 QUICK START GUIDE



LIMITED WARRANTY

Lockin Pty Ltd trading as Haltech warrants the HaltechTM Programmable Fuel Injection System to be free from defects in material or workmanship for a period of **12 months** from the date of purchase.

Proof of purchase, in the form of a bill of sale or receipted invoice, which indicates that the product is within the warranty period, must be presented to obtain warranty service. Lockin Pty Ltd trading as Haltech suggests that the purchaser retain the dealer's dated bill of sale as evidence of the date of retail purchase.

If the Haltech $^{\text{TM}}$ Programmable Fuel Injection System is found to be defective as mentioned above, it will be replaced or repaired if returned prepaid along with proof of purchase. This shall constitute the sole liability of Lockin Pty Ltd trading as Haltech.

To the extent permitted by law, the foregoing is exclusive and in lieu of all other warranties or representations, either expressed or implied, including any implied warranty of merchantability or fitness. In no event shall Lockin Pty Ltd trading as Haltech, be liable for special or consequential damages.

DISCLAIMER

Haltech will not be held responsible for any damage caused by the incorrect installation or tuning of this product. It is the installers responsibility to ensure the wiring connections and pinouts match that of the vehicle the unit is being installed into.

Haltech has taken all care to make sure the connections match the specified vehicles listed, but variations in wiring and connections on vehicles can occur and therefore this should be checked BEFORE the unit is installed.

Haltech highly recommends installation and tuning of this product is to be carried out by a professional, with an understanding on installing and tuning engine management systems.

Misuse of this product can destroy your engine.

WARNING

This ECU is designed and sold for Racing use only. Using this product for street / road use may be prohibited by law. Please check with your local vehicle authority before using this product.

GENERAL INSTALLATION WARNING

Avoid open sparks, flames or operation of electrical devices near flammable substances. Always disconnect the battery cables when doing electrical work on your vehicle.

Do not charge the battery with a 24 Volt truck charger or reverse the polarity of the battery or any charging unit. Do not charge the battery with the engine running as this could expose the ECU to an unregulated power supply that could destroy the ECU and other electrical equipment.

All fuel system components and wiring should be mounted away from heat sources, shielded if necessary and well ventilated. Disconnect the Haltech ECU from the electrical system whenever doing any arc welding on the vehicle by unplugging the wiring harness connector from the ECU.

After completing the installation, make sure that there are no fuel leaks, and no wiring left un-insulated in case a spark or short-circuit occurs and causes a fire. Also make sure that you follow all proper workshop safety procedures. If you're working underneath a jacked-up car, always use safety stands!

Haltech I/O Expander 12 Quick Start Guide

Congratulations on purchasing a Haltech I/O Expander 12 This *Plug and Play* product allows the user the ability to increase the functionality of their Haltech ECU by using the Haltech CAN system which is fitted to all Platinum Series ECU's.

The Haltech I/O Expander 12 instantly makes available 12 additional user configurable inputs and outputs. Simply plug in the CAN cable and start using your extra I/O.

This quick start guide will walk you through installation of the Haltech I/O Expander 12 into a vehicle. This guide is accompanied by the full service manual located on the software CD provided with the ECU that you or your tuner will need to refer to before completing your installation and configuration. The Manual can also be downloaded from the Haltech website www.haltech.com.

Included in Haltech I/O Expander 12 Kit

- Haltech I/O Expander 12
- Haltech CAN direct connection cable Black 600mm
- Quick start guide

Optional Accessories (Sold Separately)

- I/O Expander 12 Flying Lead Harness (HT049902)
- I/O Expander 12 Plug and Pin Set (HT030007)
- CAN Cable Hub Connection White available in various sizes 75mm up to 3600mm (Please contact Haltech for sizes and prices)
- CAN Cable Direct Connection Black available in various sizes 75mm up to 3600mm (Please contact Haltech for sizes and prices)

Installation

Installing the Haltech I/O Expander 12 is quick and simple there are 2 possible methods for connection to your Haltech ECU, they are outlined below:

Method 1: Direct Connection to Haltech Platinum Series ECU

 Connect the Haltech I/O Expander 12 directly to a Haltech Platinum series ECU via the CAN direct connection cable included with the kit




Figure 1 - Direct connection to Haltech ECU

Method 2: Connection Via Haltech CAN Hub (HT059990)

 Connect the Haltech I/O Expander 12 directly to the CAN Hub attached to a Haltech Platinum Series ECU (a Haltech CAN Hub Connection Cable may need to be purchased depending on your setup. Please refer to the Haltech CAN Hub quick start guide for details on connecting multiple devices to your Platinum Series ECU.)




Figure 2 - CAN Hub connection to Haltech ECU with 2 Devices

Power and Status LED's

The Haltech I/O expander 12 has two status LED's on the rear of the device. These LED's will illuminate under the following conditions

Power LED (Blue)

The Power LED is connected directly to power and will turn on and remain on when the device is powered up

Status LED (Red)

The Status LED turns on if the device is in error.

Possible causes are listed below:

- · Incorrect wiring
- · CAN Communications Fault
- · Two Identical Devices on the CAN Bus




Figure 3 - Rear View of I/O Expander Device Showing Status LED's

Wiring Harness (optional)

The Haltech I/O Expander 12 can be supplied with a 24 pin wiring harness, Connections are outlined in detail below:

WARNING!

Please make sure you configure your I/O Expander 12 with your ECU using ECU Manager Software <u>before</u> you plug in the wiring harness, as outputs may turn on undesirably when power is applied if not configured.

Main Inputs

There are four main inputs to the Haltech I/O Expander 12

+12V DC Switched (Pink)

Connect this wire to a +12V DC Switched ignition source

+12V DC Battery (Red)

Connect this wire to a constant +12V DC battery supply

Signal Ground (Black / White)

Connect this wire to the signal ground on the ECU

Ground (Black)

Connect this wire to a chassis ground point on the vehicle




Figure 4 - Main inputs

Analogue Voltage Inputs (AVI)

The Haltech I/O Expander 12 features 4 Analogue Voltage Inputs. Analogue Voltage Inputs accept variable voltage inputs from 0V to 5V. AVI inputs can also accept switch inputs that change between two different voltage levels. The *On Voltage* and *Off Voltage* define the thresholds between the *On* and *Off* states. The input voltage can be viewed as a channel in the software to determine the thresholds for a switched input.

Each AVI has a selectable 1K Pull up resistor which can be enabled or disabled in the software allowing guick connection of temperature sensors.

The Haltech I/O Expander 12 harness supplies connections for 5V power and signal ground outputs allowing quick and easy connection of 5V powered sensors.




Figure 5 - Analogue Voltage Inputs




Figure 6 - Haltech HT010302 Coolant Temperature Sensor wiring to AVI 1

Digital Pulsed Outputs (DPO)

The Haltech I/O Expander 12 features 4 Digital Pulsed Outputs. Each output has been grouped with a +12V DC Source within the harness, this allows the user to fit an external relay to control high current devices.

Digital Pulsed outputs are capable of outputting pulsed waveforms with varying duty and frequency. DPO's can be used to control various devices such as thermo fans, shift lights, bypass air control valves, boost control solenoids etc.

When a Digital Pulsed output is activated by the ECU the output will switch to ground. Solenoid valves and shift lights etc can be run directly from the output. However high current devices such as thermo fans and additional fuel pumps must be activated through a relay. This way the DPO is only switching a relay and not a high current draw device.

Digital Pulsed Outputs are limited to 1A Max current draw.




Figure 7 - Digital Pulsed Outputs




Figure 8 - Digital Pulsed Output Relay Wiring

Digital Pulsed Inputs (DPI)

The Haltech I/O Expander 12 features 4 Digital Pulsed Inputs. Each input has been grouped with a +12V DC Source and a signal ground within the harness, this allows the user to fit an external pull-up to 12V or pull- down to ground resistor if required and or to supply power to a 12V rated sensor.

Digital Pulsed Inputs are capable of accepting pulsed input information such as for a road speed sensor. These inputs measure the time periods between the pulses and can process this information to provide quantities such as road speed.




Figure 9 - Digital Pulsed Inputs




Figure 10 - Haltech HT1010608 wiring to DPI 1

Appendix



Looking into the wire side of the connector

Pin #	Description	Colour
1	Switched Ignition Input	Pink
	*Switched Ignition Ouput	Grey/Red
2	-	-
3	5V DC Output	Orange
4	12V Battery Supply	Red
5	-	-
6	-	-
7	-	-
8	-	ı
9	DPO4	Violet/Orange
10	DPO3	Violet/Red
11	DPO2	Violet/Brown
12	DPO1	Violet/.Black
13	Ground	Black
14	-	-
15	-	-
16	Signal Ground	Black/White
17	AVI4	Orange/Yellow
18	AVI3	Orange/Red
19	AVI2	Orange/Black
20	AVI1	Orange/Green
21	DPI4	Grey/Orange
22	DPI3	Grey/Brown
23	DPI2	Grey/Black
24	DPI1	Grey

^{*} Available in Haltech I/O Expander Harness Only Part # HT049902

Figure 11 - I/O Expander Pinout Information





PH: +612 9729 0999 FAX: +612 9729 0900 HALTECH HEAD OFFICE:

EMAIL: sales@haltech.com

HALTECH US OFFICE: PH: 760 598 1941 FAX: 760 598 1987

EMAIL: usa@haltech.com

See the Haltech Website for your local authorized dealer.

www.haltech.com

Version 4